

INSTALLATION INSTRUCTIONS



STEP 1

Connect your 4 Cam coupler to the 4 Cam valve by aligning the tabs on the coupler with the slots on the valve. Turn the coupler 1/4 turn clockwise so that the valve and coupler engage. Compress the coupler handle down until it locks in place and you hear it click.



STEP 2

Thread the TM1 on to the 3/4" thread on the top of your coupler. Be careful not to over tighten the TM1.



STEP 3

Attach delivery hose end marked with yellow tag to barbed spout with a hose clamp.



STEP 4

Connect dispense nozzle to the dispense hose using a hose clamp.



STEP 5

Before dispensing, open the bleed valve $\frac{3}{4}$ of a turn to allow flow. When you are finished pumping your DEF, close the valve to prevent the DEF from leaking.



TIP: If the pump has not been used for an extended period of time, it is important to begin pumping SLOWLY and allow the DEF to self-prime the pump. This will remove any crystallization that could have formed inside during long periods of non-use.