

TM1 INSTALLATION INSTRUCTIONS



STEP 1

Assemble telescopic down tube and thread in to the bottom of the pump.



STEP 2

Insert down tube in to NPS opening on drum and install hand pump, careful not to over tighten.



STEP 3

Attach delivery hose end marked with yellow tag to barbed spout with a hose clamp.



STEP 4

Connect dispense nozzle to the dispense hose using a hose clamp.



STEP 5

Before dispensing, open the bleed valve $\frac{3}{4}$ of a turn to allow flow. When you are finished pumping your DEF, close the valve to prevent the DEF from leaking.



TIP: If the pump has not been used for an extended period of time, it is important to begin pumping SLOWLY and allow the DEF to self-prime the pump. This will remove any crystallization that could have formed inside during long periods of non-use.