

TITAN TD1 DEF Pump System

Assembly and Installation Instructions Without A Flow Meter

If your TD1 pump system has a flow meter, please see the reverse side of these instructions.



STEP 1

Remove contents from box. Locate TD1 Pump, mounted on Universal Mounting Bracket, and hang equipment in desired location on IBC.



STEP 2

Connect dispense coupler to installed container valve. Engage coupler by pressing handle down until you hear it click. Using a hose clamp, attach suction hose (short hose) to barbed outlet on coupler.



STEP 3

Install 1" FBSP x 3/4" (white) straight barbed fitting to suction side of pump, (arrow on pump indicates correct side). Using a hose clamp, connect suction hose (shorter hose) to fitting.



STEP 4

Install the black straight barbed fitting to dispense side of pump. Using a hose clamp, connect the dispense hose (longer hose) to fitting.



STEP 5

Install 1" MBSP x 3/4" straight barbed stainless steel swivel fitting into Automatic Nozzle. Using a hose clamp, connect the dispense hose (longer hose) to swivel fitting.



STEP 6

Locate the hose hanger and slide the narrow lip over the desired bar on the IBC.



STEP 7

Plug system into 110v receptacle.



STEP 8

Turn system to the "on" position. You are now ready to dispense your DEF.

WHEN DISPENSING IS FINISHED, ALWAYS TURN THE PUMP TO THE "OFF" POSITION.

TITAN TD1 DEF Pump System

Assembly and Installation Instructions With A Flow Meter

If your TD1 pump system does not have a flow meter, please see the reverse side of these instructions.



STEP 1

Remove contents from box. Locate TD1 Pump, mounted on Universal Mounting Bracket, and hang equipment in desired location on IBC.



STEP 2

Connect dispense coupler to installed container valve. Engage coupler by pressing handle down until you hear it click. Using a hose clamp, attach suction hose (short hose) to barbed outlet on coupler.



STEP 3

Install 1" FBSP x 3/4" (white) straight barbed fitting to suction side of pump, (arrow on pump indicates correct side). Using a hose clamp, connect suction hose (shorter hose) to fitting.



STEP 4

Install the black straight barbed fitting to dispense side of pump. Using a hose clamp, connect the dispense hose (longer hose) to fitting.



STEP 5

Locate the hose hanger and slide the narrow lip over the desired bar on the IBC.



STEP 6

Install 1" MBSP x 3/4" straight barbed stainless steel swivel fitting into Automatic Nozzle. Using a hose clamp, connect the dispense hose (longer hose) to swivel fitting.



STEP 7

Plug system into 110v receptacle.



STEP 8

Turn system to the "on" position. You are now ready to dispense your DEF.

WHEN DISPENSING IS FINISHED, ALWAYS TURN THE PUMP TO THE "OFF" POSITION.