

# TITAN COUPLER CONNECT

Step 1



Insert Coupler

Step 2



Turn Handle  
Clockwise

Step 3



Push Down  
Handle

Step 4



Handle Remains  
in Locked Position

# TITAN COUPLER DISCONNECT

Step 1



Lift Up Handle  
Button

Step 2



Handle Unlocks  
and Releases

Step 3



Turn Handle  
Counter-Clockwise

Step 4



Lift Up to Remove