

TM1 INSTALLATION INSTRUCTIONS



STEP 1
Assemble the telescopic
down tube.



STEP 2
Thread tube into bottom of
pump and hand TIGHTEN.



STEP 3
Insert pump assembly into
the opening on top of a 55
gallon drum and tighten.



STEP 4
Attach delivery hose to barbed
spout with hose clamp
(included). Open the bleed
valve (blue knob) 3/4 of a turn
before dispensing. Close when
finished to prevent leaking.



TITAN TIP:

If the TM1 pump has not been used for an extended period of time, it is important to begin pumping SLOWLY and allow the DEF to self-prime the pump. This will remove any crystallization that could have formed inside during long periods of non-use.

